



# TrekAway

SERIES



**NEW**



**Great for:**

- Power Chairs
- Scooters
- Snow Blowers
- Yard Equipment
- Etc.



**Ramp Stays Secure**



## Specifications

Model Number	MT3000
Platform Dimensions	51"L x 32"W x 8"H
Inside Platform Dimensions	48"L x 30"W x 6¾"H
Ramp Dimensions	48"L x 26"W
Class III & IV Load Capacity	350 lbs.
Class II Load Capacity	350 lbs. - refer to vehicle owner's manual
Surface	Slip resistant traction tape
Compatibility	Class II*, III or IV Hitch
Weight of Carrier	70 lbs.

\*Class II Hitch requires optional *Class II Hitch Adapter*.

**Introducing the new Hitch Mounted Carrier with Ramp now available from the leading manufacturer of portable access ramps.**

- Welded construction for superior strength; no assembly required
- Little or no maintenance
- Made with a steel underframe for greater weight capacity
- Completely powder coated plus an aluminum platform and ramp that is corrosion resistant
- Optional *Hitch Height Adapter* available for vehicles with hitch clearance less than 12"
- Optional *Class II Hitch Adapter* for 1¼" hitch receiver

**Made In The USA**

**Prairie View Industries, Inc.**

FOR MORE INFORMATION CALL **1-800-554-7267**

Email: [info@pviramps.com](mailto:info@pviramps.com) ♦ [www.pviramps.com](http://www.pviramps.com) ♦ Fax 402-729-4058

