

# EZ Tow Trailer

The fully enclosed EZ Tow Trailer is spacious, lightweight, and easy to load. Perhaps most importantly, it lets you load and carry the largest scooters and power chairs even with today's compact, fuel-efficient vehicles. Thanks to the one-piece, roto-molded lightweight outer shell, you'll hardly notice that you are towing the EZ Tow Trailer, even using a vehicle as small as a Toyota Prius, Ford Focus, or Chevy Aveo. In fact, it places only 35 to 65 pounds of downward pressure on your vehicle's hitch.

The EZ Tow Trailer isn't just lightweight, it has been designed to work hard, starting with the EZ Lube hubs and Torsion axles that are preloaded with 20% of their capacity. The Torsion axles also offer fully independent suspension that virtually eliminates side-to-side shock transfer. This means the EZ Tow travels smoothly, even when it's empty. Not only will your scooter or power chair be treated with kid gloves, items such as electronics, computers, and medical equipment can be transported safely.

Loading the EZ Tow Trailer requires less than 12 ounces of force to lower the rear ramp. From there, simply guide your scooter or power chair into the trailer, secure it, and raise the rear ramp back up. Of course other items such as bicycles, electric scooters, ATVs, yard maintenance & landscaping equipment, and tables and chairs can easily be loaded into the EZ Tow Trailer.

Standard equipment includes safety chains legal in all of North America, brake lights, a license plate light, a 4 prong plug, and a removable tongue hitch.



## SPECS

Cargo Capacity	800 lbs.
Ramp Capacity	400 lbs.
Trailer Weight	344 lbs.
Usable Length	5'
Usable Width	4'
Usable Height Max	4' 2"
Door Opening	46" w x 46" h
Floor Height	12"
Hitch Type	Ball Mount